


CASCATA

ALABASTER PENDANT LIGHT



EN/AR
INSTALLATION
AND CARE GUIDE

Please retain for future reference

LUSO



EN INTRODUCTION

Thank you for purchasing from the lighting collection.

Please read this guide carefully before installing, using and cleaning this product, and retain it for future reference.

If you have any queries in relation to this product or guide, please contact our Customer Service team on 020 3370 4057.

EN TECHNICAL SPECIFICATIONS

Light Type:	LED
Voltage:	220-240V
Kelvin Rating:	3000K
IP Rating:	IP 20
Lumens:	1030lm
Light Colour:	Warm White

EN PRODUCT KIT

- A** Wall Plugs
- B** Hanging Board
- C** Screws (x2)
- D** Wiring Harness
- E** Backplate
- F** Countersunk Screws (x2)
- G** Light

EN INSTALLATION STEPS

Please note, we recommend that this product is installed by a fully qualified electrician.

- 1** Before installation, locate the fuse box and turn off the power to the relevant circuit. Next, make sure to test the existing switch/socket to confirm that the power is turned off.
- 2** Check and confirm the existing electrical box is compatible with the ceiling fixture and can support its weight.
- 3** Using the hanging board part B, mark the hole spacing on the ceiling.
- 4** Secure Bolt A to the ceiling, ensuring precise alignment with the hole spacing on hanging board B.
- 5** Before proceeding, adjust the pendant cable to your desired drop length. The pendant drop can be set anywhere between a minimum of 65 cm and a maximum of 135 cm. Ensure the cable is securely fastened and the adjustment is locked in place before continuing with installation.
- 6** Attach hanging board B to Bolt A using Screw C. Ensure all screws are firmly tightened to provide a stable foundation for the pendant fixture.
- 7** Connect the wiring harness D from the pendant body to the ceiling wires.
- 8** Position the ceiling plate E over the hanging board B, and fasten securely using screw F. The plate should sit flush against the ceiling.

Please refer to page 2 for the corresponding product diagram.

EN CARE INSTRUCTIONS

To clean and maintain the flawless finish of this product, please follow the below instructions. Improper maintenance will void your product guarantee.

- ✓ Clean with a soft cloth.
- ✓ To remove surface marks, please use a neutral cleanser without coarse grained powder.
- ✗ Do not use acidic cleansers.
- ✗ Do not use abrasive cleansers or cloths.

Go to Lusso.com to activate your guarantee.

مقدمة

نشكرك على الشراء من مجموعة الإضاءة.

يرجى قراءة هذا الدليل بعناية قبل تثبيت هذا المنتج واستخدامه وتنظيفه،
احتفظ بها للرجوع إليها في المستقبل.

إذا كان لديك أي استفسارات فيما يتعلق بهذا المنتج أو الدليل، يرجى الاتصال بنا
فريق خدمة العملاء على الرقم 0 3370 4057.

المواصفات الفنية

نوع الضوء:	قاد
الجهد الكهربى:	220-240 فولت
تصنيف كلفن:	3000 كلفن
تصنيف IP:	IP 20
لومن:	1030 لومن
لون فاتح:	الأبيض الدافئ

مجموعة المنتج

مقابس الحائط
لوحة تعليق ب
براغي (x2) C
د تسخير الأسلاك
اللوحة الخلفية
F براغي غاطسة (x2)
جي لايت

خطوات التثبيت

يرجى ملاحظة أننا نوصي بأن يتم تثبيت هذا المنتج بواسطة كهربائي مؤهل بالكامل.

1 قبل التثبيت، حدد موقع صندوق المصاهر وأوقف تشغيل الطاقة عن الجهاز ذي الصلة الدائرة. بعد ذلك، تأكد من اختبار المفتاح/المقبس الحالي للتأكد من أن تم إيقاف الطاقة.

2تحقق وتأكد من أن الصندوق الكهربائي الحالي متوافق مع تركيبات السقف ويمكنه أن يتحمل وزنه.

3 باستخدام لوحة التعليق الجزء B، قم بتحديد مسافة الفتحة في السقف.

4قم بتأمين البرغي A بالسقف، مع التأكد من محاذاة دقيقة مع مسافة الفتحات الموجودة على اللوحة المعلقة B.

5 قبل المتابعة، اضبط كابل المعلقة على طول القطر المطلوب. يمكن ضبط ارتفاع المصباح المعلق بين 65سم كحد أدنى و531سم كحد أقصى. تأكد من تثبيت الكابل بإحكام وتثبيت الضبط قبل متابعة التركيب.

6قم بربط لوح التعليق B بالمسمار A باستخدام المسمار C. تأكد من ربط جميع البراغي بإحكام لتوفير أساس ثابت لتركيبات الإضاءة المعلقة.

7قم بتوصيل حزمة الأسلاك D من جسم المصباح المعلق إلى أسلاك السقف.

8ضع لوحة السقف E فوق اللوحة المعلقة B، ثم ثبتها بشكل آمن باستخدام المسمار F. يجب أن تكون اللوحة مثبتة بشكل مسطح على السقف.

تعليمات العناية

لتنظيف هذا المنتج والحفاظ على مظهره المثالي، يُرجى اتباع التعليمات التالية. الصيانة غير السليمة تُلغي ضمان المنتج.

□ نظف بقطعة قماش ناعمة.

لإزالة العلامات السطحية، يرجى استخدام منظف محايد بدون مسحوق خشن الحبيبات

لا تستخدم المنظفات الحمضية.

لا تستخدم المنظفات أو الأقمشة الكاشطة.

انتقل إلى Lusso.com لتفعيل الضمان الخاص بك.

SCAN THE QR CODE TO
VIEW THIS INFORMATION IN
DIFFERENT LANGUAGES



LUSO

Machine Translated by Google
Customer Care: 020 3370 4057
International: +44 20 3370 4057